

Make your own filler

Fed up with your Model Lite filler being rock hard and unusable long before it's finished? If you mix some microballoons (e.g. Supalite) to a paste with some EzeKote it works a treat. Spread it with an offcut of very thin ply. Sets in 20 minutes and you make up only what you need. Put in a sealed container it remains usable for several hours.